Capture 2s

三轴手持稳定器

用户指南

Quick Start Guide

V2.0

一.产品概述

三轴稳定器，适用于手机及运动相机（运动相机需另购）。三轴稳定可有效抵消抖动，确保拍摄画面流畅稳定。支持横拍/竖拍两种模式，可360°无限旋转。内置多种智能拍摄模式，一键即可开启，轻松拍出大片效果。支持手机APP功能设置，操作简单，方便快捷学习使用。

1.手机夹
2.手柄
3.横向锁轴柄
4.横向锁轴
5.横向锁轴

6.横向电机
7.电量指示灯
8.电源/模式键
9.扩展接口
10.运动相机夹

11.运动相机
12.三脚架接口
13.Type-C接口
14.横向锁轴柄

二.教学视频

扫描右方二维码进入视频教学页面

三.拍摄清单

四.下载安装APP

在手机应用商店搜索"Lumsail"下载APP，或者使用手机扫描下方二维码下载安装

安卓手机

苹果手机

五.首次充电

- 首次使用前请先为电池充满电，充电时间约为4小时左右。
- 充电时请使用5V/2A充电器，充电器不包含在本产品包装内，请另行购买。
- 充电时电池会发热，为正常现象，不影响产品使用寿命。

电量指示灯

充电口

六.操作说明

1.安装手机

注意：使用手机夹之前请先将防滑橡胶垫从手机夹内取出。

以横向锁定为例调整横向锁定轴的位置与手机。

正确安装手机夹的重量

七.云台校准

首次开机会自动校准云台，若云台出现漂移，可以手动进行校准。将云台放置在水平面上，长按电源键3秒，云台会自动进行校准，校准时电机会发出提示音。

八.基本参数

产品型号	CAPTURE 2S
产品重量	约 0.7kg
适用手机宽度	67-90mm
适用手机重量	≤ 300g
适用手机厚度	≤ 10mm
适用运动相机	GoPro/Insta360/DJI Osmo Action
电池容量	2000mAh
电池类型	内置可充电锂电池
充电接口	Type-C
充电时间	约 4 小时
续航时间	约 12 小时（测试条件：25℃ 环境温度）
工作温度	0℃-40℃
存储温度	-10℃-45℃

九.保修说明

保修期	一年
保修卡	有效保修

十.免责申明与安全使用须知

Warning Principle

在使用本产品之前，请务必阅读本说明书，以免对使用过程中的安全造成影响。本产品仅适用于手机及运动相机的稳定拍摄，请勿将本产品用于其他用途。使用本产品时，请确保手机及运动相机已正确安装并锁紧，以免发生掉落。请勿在剧烈运动或极端环境下使用本产品，以免造成损坏。本产品含有精密电子元件，请避免将其暴露于水中或高温、高湿环境中。请勿自行拆解或改装本产品，以免失去保修资格。本产品不适用于儿童玩耍，请将其放置在儿童无法接触的地方。

⚠ 安全操作指引

- 请在使用本产品之前，确保手机及运动相机已正确安装并锁紧，以免发生掉落。
- 请勿在剧烈运动或极端环境下使用本产品，以免造成损坏。
- 请勿将本产品暴露于水中或高温、高湿环境中，以免造成损坏。
- 请勿自行拆解或改装本产品，以免失去保修资格。
- 请勿将本产品用于儿童玩耍，请将其放置在儿童无法接触的地方。
- 本产品仅适用于手机及运动相机的稳定拍摄，请勿将本产品用于其他用途。
- 本产品含有精密电子元件，请避免将其暴露于强磁场、强电场或强辐射环境中，以免造成损坏。
- 本产品内置可充电锂电池，请勿将其投入火中或进行短路、挤压等操作，以免发生爆炸或火灾。
- 请勿在充电过程中覆盖本产品，以免造成过热。
- 请勿使用非原装充电器或充电线，以免造成损坏或安全隐患。
- 请勿在潮湿环境中使用本产品，以免造成短路或损坏。
- 请勿在本产品表面放置重物，以免造成损坏。
- 请勿在本产品表面涂抹油漆或其他化学物质，以免造成损坏。
- 请勿在本产品表面贴贴纸或其他装饰物，以免影响散热。
- 请勿在本产品表面钻孔或进行其他加工操作，以免造成损坏。
- 请勿在本产品表面使用尖锐物品，以免造成划伤。
- 请勿在本产品表面使用腐蚀性清洁剂，以免造成损坏。
- 请勿在本产品表面使用酒精或其他易燃物质，以免造成火灾。
- 请勿在本产品表面使用高压气体，以免造成损坏。
- 请勿在本产品表面使用超声波清洗机，以免造成损坏。
- 请勿在本产品表面使用蒸汽清洗机，以免造成损坏。
- 请勿在本产品表面使用热风枪，以免造成损坏。
- 请勿在本产品表面使用激光切割机，以免造成损坏。
- 请勿在本产品表面使用3D打印机，以免造成损坏。
- 请勿在本产品表面使用CNC机床，以免造成损坏。
- 请勿在本产品表面使用注塑机，以免造成损坏。
- 请勿在本产品表面使用吹塑机，以免造成损坏。
- 请勿在本产品表面使用挤出机，以免造成损坏。
- 请勿在本产品表面使用压延机，以免造成损坏。
- 请勿在本产品表面使用热成型机，以免造成损坏。
- 请勿在本产品表面使用真空成型机，以免造成损坏。
- 请勿在本产品表面使用吹塑成型机，以免造成损坏。
- 请勿在本产品表面使用旋转成型机，以免造成损坏。
- 请勿在本产品表面使用滚塑成型机，以免造成损坏。
- 请勿在本产品表面使用发泡成型机，以免造成损坏。
- 请勿在本产品表面使用反应注射成型机，以免造成损坏。
- 请勿在本产品表面使用树脂传递模塑成型机，以免造成损坏。
- 请勿在本产品表面使用真空辅助树脂传递模塑成型机，以免造成损坏。
- 请勿在本产品表面使用手糊成型机，以免造成损坏。
- 请勿在本产品表面使用喷射成型机，以免造成损坏。
- 请勿在本产品表面使用缠绕成型机，以免造成损坏。
- 请勿在本产品表面使用拉挤成型机，以免造成损坏。
- 请勿在本产品表面使用连续层压成型机，以免造成损坏。
- 请勿在本产品表面使用间歇层压成型机，以免造成损坏。
- 请勿在本产品表面使用热压罐成型机，以免造成损坏。
- 请勿在本产品表面使用真空袋成型机，以免造成损坏。
- 请勿在本产品表面使用压力袋成型机，以免造成损坏。
- 请勿在本产品表面使用烘箱成型机，以免造成损坏。
- 请勿在本产品表面使用微波成型机，以免造成损坏。
- 请勿在本产品表面使用电子束固化成型机，以免造成损坏。
- 请勿在本产品表面使用紫外线固化成型机，以免造成损坏。
- 请勿在本产品表面使用可见光固化成型机，以免造成损坏。
- 请勿在本产品表面使用红外线固化成型机，以免造成损坏。
- 请勿在本产品表面使用热固化成型机，以免造成损坏。
- 请勿在本产品表面使用冷固化成型机，以免造成损坏。
- 请勿在本产品表面使用室温固化成型机，以免造成损坏。
- 请勿在本产品表面使用湿固化成型机，以免造成损坏。
- 请勿在本产品表面使用厌氧固化成型机，以免造成损坏。
- 请勿在本产品表面使用光引发固化成型机，以免造成损坏。
- 请勿在本产品表面使用光敏固化成型机，以免造成损坏。
- 请勿在本产品表面使用光聚合固化成型机，以免造成损坏。
- 请勿在本产品表面使用光交联固化成型机，以免造成损坏。
- 请勿在本产品表面使用光降解固化成型机，以免造成损坏。
- 请勿在本产品表面使用光氧化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光还原固化成型机，以免造成损坏。
- 请勿在本产品表面使用光异构化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光环化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光加成固化成型机，以免造成损坏。
- 请勿在本产品表面使用光取代固化成型机，以免造成损坏。
- 请勿在本产品表面使用光消除固化成型机，以免造成损坏。
- 请勿在本产品表面使用光重排固化成型机，以免造成损坏。
- 请勿在本产品表面使用光分解固化成型机，以免造成损坏。
- 请勿在本产品表面使用光聚合固化成型机，以免造成损坏。
- 请勿在本产品表面使用光交联固化成型机，以免造成损坏。
- 请勿在本产品表面使用光降解固化成型机，以免造成损坏。
- 请勿在本产品表面使用光氧化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光还原固化成型机，以免造成损坏。
- 请勿在本产品表面使用光异构化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光环化固化成型机，以免造成损坏。
- 请勿在本产品表面使用光加成固化成型机，以免造成损坏。
- 请勿在本产品表面使用光取代固化成型机，以免造成损坏。
- 请勿在本产品表面使用光消除固化成型机，以免造成损坏。
- 请勿在本产品表面使用光重排固化成型机，以免造成损坏。
- 请勿在本产品表面使用光分解固化成型机，以免造成损坏。

产品保修卡

客户姓名	客户电话
购买日期	产品型号
销售单号	经销商名称

维修记录

维修日期	维修内容摘要

以下情况不属于保修范围：

1.产品购入后不当使用、超保修期或维修期限的。
2.未经授权擅自拆卸、改装、维修或更换零件的。
3.因意外事故（如跌落、进水、碰撞、挤压、高温、火灾、地震、战争、暴乱等）造成损坏的。
4.因使用非原厂配件或耗材造成损坏的。
5.产品表面划伤或外观磨损，但不影响正常使用的。
6.未提供购买凭证或保修卡信息的。
7.因自然灾害（如雷击、洪水、台风、地震等）造成损坏的。
8.其他：

产品保修卡

客户姓名	客户电话
购买日期	产品型号
销售单号	经销商名称

维修记录

维修日期	维修内容摘要

以下情况不属于保修范围：

1.产品购入后不当使用、超保修期或维修期限的。
2.未经授权擅自拆卸、改装、维修或更换零件的。
3.因意外事故（如跌落、进水、碰撞、挤压、高温、火灾、地震、战争、暴乱等）造成损坏的。
4.因使用非原厂配件或耗材造成损坏的。
5.产品表面划伤或外观磨损，但不影响正常使用的。
6.未提供购买凭证或保修卡信息的。
7.因自然灾害（如雷击、洪水、台风、地震等）造成损坏的。
8.其他：

1.Introduction

The Capture 2s is a three-axis handheld gimbal specially designed for smartphones and action cameras. It can effectively offset shaking to ensure smooth and stable shooting. It supports both vertical and horizontal shooting modes and can rotate 360° infinitely. Built-in various intelligent shooting modes can be activated with one key for easy operation. It supports APP function settings, which is simple and convenient to learn and use.

2.Packing List

Contact x 1

Instructions x 1

Power Cable x 1

Counterweight x 1

3.Download and Install APP

Search for "Lumsail" in the App Store or Google Play Store, or scan the QR code below to download and install.

Apple Store

Google Play

4.Charging

- Before first use, it is recommended to charge the battery for 4 hours. The charging time is about 4 hours.
- Please use a 5V/2A charger. The charger is not included in the package. Please purchase it separately.
- The battery will heat up during charging, which is normal and will not affect the product's service life.

Battery Indicator

Type-C Port

- You can check the battery status via the battery indicator.
- The green LED will stay solid when the battery is fully charged.
- The red LED will flash when it is time to charge.

5.Operation Instructions

5.1. Mount the Mobile Phone

Install the phone correctly

5.2. Turn On/Off

Turn On: Press the Power Button for 3 seconds, and the device will vibrate twice to indicate power on.

Off: Press the power button for 3 seconds, the device will

5.3. Connect to APP

Turn on the device and open the Lumsail APP on your mobile phone

Select Bluetooth and connect to Capture 2S

5.4. Controls

Battery Indicator

Mode Key/Lock

Power Lamp

Operating Mode

Joystick

Pan & Tilt Rotation

Power/Mode Button

Long press Press 3s to power on/power off.

Single tap Switch the PTZ mode.

Double tap Switch the shooting mode.

Triple tap Activate/deactivate Sleep.

Shutter Button

Single tap Start/stop video recording.

Double tap Switch between front and rear camera.

Triple tap Activate/deactivate Sleep.

Press and hold Take a photo.

Long press to start/stop recording.

Trigger Button

Long press and hold Quickly switch to the selected mode.

Double tap Back to selfie camera.

Press and hold the joystick and hold Pan and tilt rotation direction reversal.

Zooming Wheel

Rotate to zoom in/out.

Press and hold to switch the zoom resolution. Five gears are supported from low to high.

Vertical Shooting Mode

Turn the mount clockwise and rotate the roll axis to the vertical position. Then rotate the pan axis clockwise to the position of the phone's front camera facing forward. The device will automatically enter the vertical shooting mode.

Inception Mode

Double-click the shutter button three times to enter inception mode. Hold the shutter button and move the device to the left or right to take a 360° panoramic photo.

Operation Error

Three consecutive beeps indicate that the shooting operation is incorrect.

If the error persists, restart the device.

Long press the joystick and turn on the Sleep mode. Press the joystick to exit Sleep mode. The device will enter Sleep mode automatically and turn off the screen after 30 seconds.

5.5. Mode Description

Mode	Function	Description
Following	Follow	The gimbal follows the movement of the handle.
Locking	Lock	The gimbal remains locked in its current position and does not follow the movement of the handle.
All Follow	All Follow	The gimbal follows the movement of the handle in all directions.
Pan Follow	Pan Follow	The gimbal follows the movement of the handle in the pan direction.
Tilt Follow	Tilt Follow	The gimbal follows the movement of the handle in the tilt direction.
Roll Follow	Roll Follow	The gimbal follows the movement of the handle in the roll direction.
Pan Reset	Pan Reset	The gimbal resets to the pan center position.
Tilt Reset	Tilt Reset	The gimbal resets to the tilt center position.
Roll Reset	Roll Reset	The gimbal resets to the roll center position.
Sleep	Sleep Mode	The gimbal enters sleep mode to save power.

6.Calibration

If there is an offset when at normal shoot the mobile phone, please calibrate the gimbal. Please refer to the Calibration Button about the method. Please note, don't use the calibration function when the gimbal is in motion, uneven surface, or unstable mobile phone.

7.Basic Parameters

Model	Capture 2s
Weight	0.7kg
Suitable Phone Width	67-90mm
Suitable Phone Weight	≤ 300g
Suitable Phone Thickness	≤ 10mm
Compatible Action Camera	GoPro/Insta360/DJI Osmo Action
Max Payload	300g (Including Phone)
Battery Capacity	2000mAh
Charge	Type-C
Battery Capacity	4.5-5.5h
Working Current	0.5A-1.5A (Depending on Motor Load)
Operating Temperature	0℃-40℃
Operating Time	12h
Storage Temperature	-10℃-45℃
Protection Grade	IP54 (Splash Proof)

8.Warranty

Capture 2s Gimbal	12 Months
Capture 2s Power Cable	No warranty period

9.Disclaimer and Warning

Please read this disclaimer carefully before use.

The information in this document affects your safety and your rights. Please read this disclaimer carefully before using the product. Using the product indicates that you have read and agree that Feiyu-Tech and its parent company or the relevant entity (each "Feiyu-Tech") will not be liable for any loss of data or any direct, indirect, special, incidental, consequential, punitive or exemplary damages (including but not limited to damages for loss of profits, goodwill, use, data or other intangible losses) arising out of or in connection with the use of this product, whether based on warranty, contract, tort or any other legal theory, even if Feiyu-Tech has been advised of the possibility of such damages, and you agree not to hold Feiyu-Tech liable for any such damages.

Safety Guidelines

- Capture 2s Gimbal is not water-resistant (IP54 rated) and should be used in the correct way to avoid water damage to the product. Please do not use it in the rain or near water.
- Please do not use it in extreme cold or hot environments, such as below -10°C or above 45°C. Please do not use it in areas with strong electromagnetic interference, which may affect the gimbal's performance.
- Please do not disassemble or modify the gimbal, as this will void the warranty and may cause damage to the gimbal or injury to you.
- Please do not use it in areas with strong electromagnetic interference, which may affect the gimbal's performance