




Mobile Phone Neck Bracket



User Guide


Recommend usage methods

In complex environments, wading environments, or running and jumping and other high-intensity sports scenes, including but not limited to fishing, mountain biking, running, skateboarding, etc., please be sure to match with the magnetic phone case + security strap + safety rope




1. Wear

insert the lock latch from top to bottom




2. Unlock

Toggle the top button to unlock the lanyard latch.




3. Adjustment

Adjust the stand to a suitable angle




4.1 The phone comes with a magnetic tab for mounting

The back of the mobile phone aligned with the magnetic ring automatically adsorption (Note: the magnetic ring adsorption is only applicable to the mobile phone with its own magnetic suction piece)




4.2 Mobile Phone Clip Installation

If the mobile phone does not have a magnetic sheet, please use the mobile phone clip to fix the mobile phone.



5. Install the strap

Adjust the length of the strap



6. Adjust the Strap

Adjust the length of the strap

Note

1. When using the product, please check whether the product accessories and devices can be used normally, to avoid unnecessary accidents, damage to the camera and mobile phones and other shooting equipment.
2. Please do not disassemble or use the product violently to avoid damage or insensitivity of the product and the device, which may cause damage to the shooting equipment.
3. In order to improve the service life of the product, please do not bend the silicone chain in the same position repeatedly and quickly.
4. Please do not touch the product or close to the heat source, so as not to deform the silicone by high temperature.
5. Do not allow the product to come into contact with or near strong chemicals.